FURYCUBE

REVOLUTION × INNOVATION

M30 HE

MAGNETIC KEYBOARD

驱动下载和固件升级

前往FURYCUBE官网: furycube.com，可下载最新驱动程序和进行固件升级，体验键盘完整功能。

Download and Update of Driver

FURYCUBE Official Website: **furycube.com,**To enjoy complete functionality.



Fn + T :

切换灯条灯效

Change light strip effect

Fn + R :

切换侧灯亮度 要求有5级亮度调节，默认最亮; 循环切换

Switch the side light brightness. Requires 5 levels of brightness adjustment, the default is the brightest; Cycle switch

Fn + G :

打开/关闭侧灯条

Turn on/off side light

第一层功能
First level function

第二层功能
Second level function

Fn + [ ] : 整版切换第二层功能
Switch the second level function of the whole page

键盘右侧独立指示灯说明

1. 第一层按键功能：
Caps Lock按键对应指示灯变化
- 大写状态：激活后亮蓝色光
- 状态切换：返回小写时蓝光熄灭，恢复为原设定灯效

2. 第二层按键功能：
FN+空格组合键切换，对应指示灯变化
- 切换后：大写模式亮蓝光，小写模式亮白光
- 再切换：恢复至按第一层按键功能

3. 默认状态
当无功能激活时，维持原设定灯效

Tips for the indicator on the right side of the keyboard

1. First-layer key function:
Caps Lock key functions as the indicator changes
- Uppercase state: blue light on after activation
- State switch: blue light off when returning to lowercase, and the original setting light effect is restored

2. Second-layer key function:
FN+Space key combination for switch, accordingly indicator changes
- After switching: in uppercase mode, the light turns on blue; in lowercase mode, it turns on white
- Switch again: restore to the first-layer key function

3. Default state
When no function is activated, it stays at the original setting light effect

FURYCUBE

REVOLUTION · INNOVATION

M30 HE

Magnetic keyboard manual

System Requirement:

Win8/Win10/Win11 (driver incompatible with Win7 and below system /MAC)
USB interface (2.0/3.0/3.1/3.2)

Installation Steps:

When starting the computer, in case using the keyboard for the first time, you need to wait the driver automatically installed. Keyboard driver is installed to get more functional settings.
Driver download : https://driver.furycube.com/

Function Key Combination(FN)

1! = F1	Tab = Restore factory settings
2@ = F2	A = Backlight Color
3# = F3	D = Turn ON/OFF the Backlight
4¥ = F4	X = Backlight Brightness+
5% = F5	S = Backlight Speed
6^ = F6	Z = Backlight Brightness-
ESC = .~	C = Backlight Mode

B = Returns to the regulated condition
Keep pressing for 5 seconds until the backlit turns red and the keyboard returns to the unregulated condition.

Q = G1 Normal Mode
• Button triggered stroke 2.0mm • Quick trigger (RT) off (Factory default settings)

W = G2 Game Mode
• Button triggered stroke 1.5mm • Rapid Trigger (RT) 0.2mm

E = G3 Competitive Mode
• Button triggered stroke 1.0mm • Rapid Trigger (RT) 0.1mm

Function Key Combination:



First level function

Second level function

Fn + [ ] = Switch the second level function of the whole page

---

Fn + T = Change light strip effect

Fn + R = Switch the side light brightness. Requires 5 levels of brightness adjustment, the default is the brightest; Cycle switch

Fn + G = Turn on/off side light